



1863 Eastman Ave.
Ventura, Ca. 93003
www.arp-bolts.com

Part Number: 201-2801 & 201-2802

Application: BMW 2.3L (S14) 4-CYL

Flywheel Bolt without Washer- Installation

- [1] Please check the part-number(s) for your application against the part-number(s) listed on the instruction sheet.
- [2] **DO NOT USE ANY WASHERS** with ARP Flywheel Bolts. They are designed to be installed without them. **Note:** ARP will NOT be responsible for any failures resulting from using a washer with this kit.
- [3] Make sure there is an adequate chamfer around the bolt holes on the flywheel to clear the radius under the head of the bolt.
- [4] Lubricate the threads of the bolt with **LOCTITE 270** and the under head of the bolt with **ARP ULTRA-TORQUE FASTENER ASSEMBLY LUBRICANT**. Then install the flywheel onto the crankshaft and tighten the bolts hand tight.
- [5] Using an alternating or criss cross pattern, torque the bolts to **105 ft lbs using the specified lubricants in Step 4. NOTE: LOCTITE 270 IS USED ON THE BOLT THREADS TO PREVENT OIL LEAKS ON THIS PARTICULAR APPLICATION.**

If you have any questions or need additional information please contact us at **(805) 339-2200** or by FAX at **(805) 650-0742**